


# RIVIAL

Via G. Pastore,11 43058 SORBOLO (PR) - ITALIA

## AUTOMATIC LUBRICATING PUMP AT 3 DELIVERIES



# RIVIAL

Via G. Pastore,11 43058 SORBOLO (PR) - ITALIA

## AUTOMATIC LUBRICATING PUMP AT 3 DELIVERIES

### TECHINICAL DATA AND INSTRUCTIONS

|                     |       |        |
|---------------------|-------|--------|
| Total capacity      | g/h   | 0-720  |
| Max rev.            | n/min | 2000   |
| Ratio               | R     | 33:1   |
| Deliveries          | N°    | 3      |
| Max pressure        | bar   | 2,5    |
| Max suction height  | mm    | 250    |
| Piston diam.        | mm    | 7,17   |
| Suction hole diam.  | mm    | 6x4    |
| Delivery hole diam. | mm    | 4x2    |
| Weight              | kg    | 1,050  |
| Delivery hole       | /     | 1/8" G |
| Suction hole        | /     | 1/8" G |
|                     |       |        |
|                     |       |        |
|                     |       |        |

### **HOW TO USE IT**

The automatic lubrication pump doesn't require any special maintenance during operation. Always make sure to have oil into the machine feed tank and at least every 5-6 months check lubricating oil/grease level into the pump tank under the cover; if required add oil/grease without completely fill the tank.


### **LUBRICATING FLOW CONTROL**

In case you need a lower or higher oil delivery, operate the register pin. Turn clockwise to have a lower oil delivery (-); turn anticlockwise to have a higher oil delivery (+).

# RIVIAL

Via G. Pastore,11 43058 SORBOLO (PR) - ITALIA

## AUTOMATIC LUBRICATING PUMP AT 3 DELIVERIES



## SPARE PARTS AUTOMATIC LUBRICATING PUMP AT 3 DELIVERIES

# RIVIAL

Via G. Pastore,11 43058 SORBOLO (PR) - ITALIA

## AUTOMATIC LUBRICATING PUMP AT 3 DELIVERIES

### SPARE PARTS CATALOGUE AUTOMATIC LUBRICATING PUMP AT 3 DELIVERIES

| ART.   | DESIGN | DESCRIPTION                      | PCS. |
|--------|--------|----------------------------------|------|
| P3M-01 | 1001/M | A.L. PUMP CASE AT 3 DELIVERIES   | 1    |
| P3M-02 | 1623DX | PUMP COVER - RIGHT               | 2    |
| P3M-03 | 1625SX | PUMP COVER - LEFT                | 2    |
| P3M-04 | 1632   | REGISTER PIN COVER               | 2    |
| P3M-05 | 1605   | REGISTER PIN                     | 2    |
| P3M-06 | 1630DX | TIMING GEAR- RIGHT               | 1    |
| P3M-07 | 1602   | SPRING                           | 1    |
| P3M-08 | 1616   | BACK PLUG                        | 1    |
| P3M-09 | 1610   | NUT                              | 2    |
| P3M-10 | 1608   | PUMP COVER GASKET                | 2    |
| P3M-11 | 1612   | SPRING SUPPORT                   | 2    |
| P3M-12 | 1613   | OIL SEAL UNIT                    | 1    |
| P3M-13 | 1626   | DELIVERY CLOSURE PLUG            | 1    |
| P3M-14 | 1614   | SCREW M4X0,7                     | 4    |
| P3M-15 | 1620DX | LONG TIMING SHAFT -RIGHT         | 1    |
| P3M-16 | 1619DX | SHORT TIMING SHAFT - RIGHT       | 1    |
| P3M-17 | 1620SX | LONG TIMING SHAFT - LEFT         | 1    |
| P3M-18 | 1619SX | SHORT TIMING SHAFT - LEFT        | 1    |
| P3M-19 | 1607DX | TIMING GEAR 2 DELIVERIES - RIGHT | 1    |
| P3M-20 | 1630SX | TIMING GEAR 1 DELIVERY- LEFT     | 1    |
| P3M-21 | 1607SX | TIMING GEAR 2 DELIVERIES- LEFT   | 1    |
| P3M-22 | 1615   | BUSHING                          | 1    |
|        |        |                                  |      |
|        |        |                                  |      |